

**Rollei A 26**  
**Rollei C 26**

**In der Praxis**  
**in practical use**  
**dans la pratique**  
**nell'uso pratico**  
**en la práctica**  
**In de praktijk**



<b>Inhalt</b>	<b>Seite</b>
Einzelteile und Funktion ...	2
Schnellkursus .....	3
Fototips für den Anfang ....	3
Vor der ersten Aufnahme ..	4
Vor jeder Aufnahme .....	5
Achtung – Aufnahme! .....	5
Nach jeder Aufnahme .....	6
Nach der letzten Aufnahme ...	6
Blitzaufnahmen mit dem C 26	6
Blitzgerät laden .....	7
Tips für die Kamerapraxis ..	8
Tips für die Blitzpraxis .....	9
Wartung und Pflege .....	10
Daten und Zahlen – A 26 ...	11
Daten und Zahlen – C 26 ...	12
Guter Rat und schnelle Hilfe	12
Beim Lesen bitte die erste und letzte Umschlagseite herausklappen	


<b>Contents</b>	<b>Page</b>
Components and function ..	14
Crash course .....	15
Hints for the beginner ....	15
Before the first picture ....	16
Before each picture .....	17
Important for shooting ....	17
After each picture .....	18
After the last picture .....	18
Flash pictures with the C 26	18
Charging flash unit .....	19
Hints for the camera .....	20
Hints for the flash .....	21
Maintenance and care ....	22
Specification – A 26 .....	23
Specification – C 26 .....	24
Handling faults and remedies	24
When reading, please open the first and the last cover leaf	

<b>Contenu</b>	<b>Page</b>
Organes et fonctions .....	26
Cours rapide .....	27
Tips pour le début .....	27
La première prise de vue ..	28
Avant chaque prise de vue ..	29
Attention – prise de vue! ..	29
La dernière prise de vue ..	30
Prise de vue avec le C 26 ..	30
Chargement du flash .....	31
Tips pour l'appareil .....	32
Tips pour le flash .....	35
Entretien et soins .....	36
Caractéristiques – A 26 ....	37
Caractéristiques – C 26 ....	38
Défauts et remèdes .....	39
Déplier la première et la dernière page de couverture, s'il vous plaît	

<b>Contenuto</b>	<b>Pagina</b>
Parti e funzioni .....	40
Corso accelerato .....	41
Per le prime riprese .....	41
Prima della prima ripresa ..	42
Prima di ogni ripresa .....	43
Attenzione – ripresa! .....	43
Dopo ogni ripresa .....	44
Dopo l'ultima ripresa .....	44
Riprese con il C 26 .....	45
Carica del lampeggiatore ..	46
Suggerimenti per l'A 26 ....	47
Suggerimenti per il C 26 ...	48
Manutenzione .....	50
Dati e cifre – A 26 .....	50
Dati e cifre – C 26 .....	51
Difetti e rimedi .....	52
Aprire i due risvolti di copertina	

<b>Índice</b>	<b>Página</b>
Componentes y función ....	54
Curso rápido .....	55
Tips para el comienzo ....	55
Antes de la primera toma ..	56
Antes de cada toma .....	57
¡Atención – toma! .....	57
Después de cada toma ....	58
Después de la última toma ..	58
Tomas con flash con el C 26	58
Cargar el aparato de flash ..	59
Tips para la cámara .....	60
Tips para el flash .....	62
Entrenimiento y cuidado ..	64
Datos y cifras – A 26 .....	64
Datos y cifras – C 26 .....	65
Errores y remedios .....	66
Sirvase abrir la primera y la última página	

<b>Inhoud</b>	<b>Bladzijde</b>
Delen en functies .....	68
Spoedcursus .....	69
Fototips voor het begin ....	69
Voor de eerste opname ....	70
Voor elke opname .....	71
Opgelet – opname! .....	71
Na elke opname .....	72
Na de laatste opname .....	72
Flitsopnamen met de C 26 ..	72
Flitsapparaat laden .....	73
Tips voor de camera .....	74
Tips voor het flitsen .....	75
Onderhoud .....	76
Technische gegevens – A 26	77
Technische gegevens – C 26	78
Fouten en verbetering .....	78
Bij het lezen de eerste en de laatste zijden uitvouwen	



## Einzelteile und Funktion

- |           |   |           |   |
|-----------|---|-----------|---|
| <b>1</b>  | Fertigungsnummer  | <b>17</b> | Schraubgewinde für Trag- bzw. Umhängeschlaufe                   |
| <b>2</b>  | Tragschlaufe  | <b>18</b> | Kontaktkupplung   |
| <b>3</b>  | Umhängeschlaufe   | <b>19</b> | Kontaktstift für Blitzgerät                                     |
| <b>4</b>  | Schraubgewinde für Blitzgerät oder Trag- bzw. Umhängeschlaufe | <b>20</b> | Befestigungsschraube für Blitzgeräatanschluß                    |
| <b>5</b>  | Griffstück  | <b>21</b> | Ein/Aus-Schalter  |
| <b>6</b>  | Schiebehülse  | <b>22</b> | Rotmarke für Schalterstellung „Ein“                             |
| <b>7</b>  | Taste mit Rotpunkt für Hülsenentriegelung                     | <b>23</b> | Kontrollampe für Blitzbereitschaft                              |
| <b>8</b>  | Rückwand mit Filmandruckplatte                                | <b>24</b> | Sensor  |
| <b>9</b>  | Sichtfenster für Filmsorte und Aufnahmezahl                   | <b>25</b> | Reflektor   |
| <b>10</b> | Entfernungssymbole  | <b>26</b> | Ladesperre für eingeschaltetes Blitzgerät                       |
| <b>11</b> | Meter/feet-Skala für Entfernungseinstellung                   | <b>27</b> | Anschluß für Ladekabel  |
| <b>12</b> | Fenster für Belichtungsmesser                                 | <b>28</b> | Ladegerät   |
| <b>13</b> | Sucherokular  | <b>29</b> | Schlitzschraube für Seitenkappe                                 |
| <b>14</b> | Sucherfenster   | <b>30</b> | Seitenkappe   |
| <b>15</b> | Grünsignal für ausreichendes Aufnahmelicht                    | <b>31</b> | Batteriefach  |
| <b>16</b> | Servo-Auslöser  | <b>32</b> | Federplatte für Batteriehalterung                               |
|           |   | <b>33</b> | Taste für Filmtransportfreilauf bei Kassettenfehlern → Seite 13 |
|           |   | <b>34</b> | Objektiv  |

## **Rollei A 26**

Eine Kamera, mit der man von Anfang an gute Bilder macht, schneller und einfacher als je zuvor. Rollei-Präzision und Vollautomatik ermöglichen eine neue Art zu fotografieren: blitzschnelle Aufnahmen bei einfachster Handhabung.

## **Rollei C 26**

Ein Computerblitzgerät im Taschenformat — zusammen mit der A 26 ein Mini-Fotoset mit eingebauter Sicherheit für gelungene Blitzaufnahmen.

Viel Freude am vollautomatischen Fotografieren mit diesen kleinen Präzisionsgeräten wünschen Ihnen die

Rollei-Werke Franke & Heidecke

## **Vor der ersten Aufnahme**

### **Fertigungs-Nummer**

der Kamera bitte notieren und aufbewahren (Nr. 1/Seite 2). Angabe dieser Nummer erleichtert Wiederbeschaffung bzw. Eigentumsnachweis bei Verlust.

### **Batterie einsetzen**

wie auf Seite 9 beschrieben (falls nicht schon von Fotohändler vorgenommen).

### **Tragschlaufe anbringen**

Je nach Bedarf Tragschlaufe **2** oder Umhängeschlaufe **3** in Gewinde **4** einschrauben.

Tragschlaufe sichert schnelle Schußbereitschaft beim Tragen am linken Handgelenk; Umhängeschlaufe erlaubt bequemes Tragen und sogar unbemerktes Mitführen der Kamera (unter Jackett oder Mantel bzw. in linker Innentasche, siehe auch Seite 8).

### **Filmkassette einlegen**

Kamera wie in Bild **A** gezeigt an beiden Griffstücken **5** halten und Hülse **6** aufziehen. Rotmarkierte Taste **7** eindrücken und Hülse **6** ganz abziehen → Bild **B**. Rückwand **8** aufklappen, Filmkassette

## Components and function

- |    |  |    |   |
|----|--|----|---|
| 1  | Serial number                                    | 17 | Strap bush  |
| 2  | Carrying strap                                   | 18 | Contact coupling  |
| 3  | Neck strap                                       | 19 | Contact pin for flash unit                                    |
| 4  | Bush for flash unit or carrying and neck strap   | 20 | Fixing screw for flash connection                             |
| 5  | Grip   | 21 | On/off switch   |
| 6  | Sliding sleeve                                   | 22 | Red mark for switch "on"                                      |
| 7  | Button with red dot for sleeve release           | 23 | Flash ready light   |
| 8  | Camera back with film pressure plate             | 24 | Sensor  |
| 9  | Window for film type and exposure number         | 25 | Reflector   |
| 10 | Focusing symbols                                 | 26 | Charge lock for flash switched on                             |
| 11 | Metre/feet focusing scale                        | 27 | Charger cord connection                                       |
| 12 | Exposure meter window                            | 28 | Charger   |
| 13 | Viewfinder eyepiece                              | 29 | Slotted head screw for side panel                             |
| 14 | Viewfinder window                                | 30 | Side panel  |
| 15 | Green signal for sufficient subject illumination | 31 | Battery compartment   |
| 16 | Servo release                                    | 32 | Battery spring retainer plate                                 |
|    |  | 33 | Film advance freewheel button for cartridge defects → page 25 |
|    |  | 34 | Lens  |

## **Crash course for the first film**

### **Cock camera**

upto stop → Fig. A.

### **Open camera**

depress locking button 7, pull off sleeve 6 → Fig. B.

### **Insert film cartridge**

open camera back 8, after inserting re-close → Fig. C, push sleeve 6 up.

### **Advance film to No. 1**

pull sleeve 6 open to its fullest extent and push closed again until '1' is visible in window 9.

### **Focus**

set focusing symbol 10 corresponding to subject → Fig. D.

### **View subject in finder**

picture area inside bright-line frame → Fig. E and F.

### **Release on green signal**

green light 15 = go ahead by pressing down release 16, subject illumination sufficient → Fig. F.

### **Where green signal absent**

connect flash unit with screw 20 → Fig. G.

### **Switch on flash unit**

Push switch 21 to the right → Fig. H.

### **Await flash ready signal**

on ready light 23 and fire → Fig. J.

## **Hints for the beginner**

- Look for lively, brightly illuminated close-up subjects, avoid drap, low contrast subjects.
- Close-up snap shots are better than posed "souvenir pictures" or pure landscape and architecture without foreground.
- A few large colour areas are better than a lot of brightly coloured detail.
- Your "ideal subject": a small group in action, at a range of about 6 to 8 m/20 to 30 ft, morning or afternoon, with sunlight coming from the side, with vivid colour contrast in front of a quiet background.
- When using flash observe a range of approximately 1 to 4 m/3½ to 13 ft, avoid sharply receding scenes, do not use frontal flash against reflective surfaces.
- See other hints and instructions on pages 20 and 25.

## **The Rollei A 26**

A camera for everybody to take good pictures right from the beginning, faster and more simply than ever before. Rollei precision and full automation permit a completely new type of photography: rapid pictures with extremely simple operation.

## **The Rollei C 26**

A pocket size computer flash unit – together with the A 26 a mini-photo-combination with built-in guarantee of successful flash pictures.

We wish you lots of fun in fully automatic photography with this miniature precision equipment from the

Rollei-Werke Franke & Heidecke

## **Before taking the first picture**

### **Serial number**

of the camera – note and keep in a safe place (number 1/page 14). Stating this number facilitates recovery or proof of ownership in the case of loss.

### **Insert battery**

as described on page 21 (if not already done by your Photo Dealer).

### **Fit carrying strap**

As required screw carrying strap 2 or neck strap 3 into bush 4.

The carrying strap ensures rapid shooting when carried on the left wrist; the neck strap permits convenient carrying and even carrying the camera unnoticed (under the jacket or coat, or in the left-hand inside breast pocket, see also page 20).

### **Insert film cartridge**

Hold camera by the two grips 5 as shown in Fig. A and pull open sleeve 6. Press in button 7 with red mark and pull sleeve 6 right off → Fig. B.



Open camera back **8**, insert film cartridge (type 126) so that the lettering is visible. Re-close camera back **8** and hold pressed against the cartridge. Push up sleeve **6** → Fig. **C** and close tight until resistance is felt.




Pull sleeve **6** open several times to its fullest extent and fully close again until the frame number **1** appears in the window **9**.

## Before each picture

### Focus

Pull open sleeve **6**, focus according to symbols **10** → Fig. **D** or to estimated distance in metres or feet between camera and important picture subject using focusing scale **11**.

Examples of frequently used settings:

 Close-up subject or portrait head and shoulders	1.2—1.5 m/ 4 to 5 ft
 Small group of people, interior shot in living rooms	2—6 m/ 6 to 20 ft
 Large groups of people, building, landscape	6 m—∞/ 20 ft to ∞

### Select picture area

Hold camera as shown in Fig. **E**: slip strap over left wrist for safety, do not mask window **12**, keep eye close to viewfinder eyepiece **13**.

Select picture area so that it is completely within the bright-line frame of viewfinder **14** → Fig. **F**.

The area surrounding the bright-line frame makes it easier to follow rapidly moving subjects.

### Important for shooting

The green signal **15** in the bottom right of the viewfinder image signifies sufficient subject illumination and gives the "go ahead" for a correctly exposed picture with a light pressure on the release **16**.

If no picture is taken: close camera again to fullest extent – no picture is lost, as now no film advance takes place. With insufficient subject illumination the green signal will not come on – for such cases the C 26 flash unit is provided → Page 18.

## **After each picture**

close camera completely and pull fully open again to be ready for shooting the next time –

read off exposure number in window 9 to permit changing the film in good time.

During intervals between shooting however always close the camera: lens and viewfinder are then protected, the release is secured against inadvertent shooting.

## **After the last picture**

The exposure No. 12 or 20 is followed in window 9 by a number of X's to indicate the film end (and film change): repeatedly close and open camera until the X's are no longer visible.

Pull off camera sleeve 6 (shading the camera with the body) after depressing button 7. Open camera back 8 and remove cartridge, insert new cartridge → Fig. B.

Have exposed films (particularly colour material) developed as soon as possible as they only have a limited storage time.

## **Flash pictures with the C 26**

are quite simple, because the built-in computer automatically ensures correct exposure. Camera operation remains the same, additional adjustments are not necessary by virtue of the automatic diaphragm control. After coupling the two units the C 26 will provide about 40 flashes for subjects at distances of approximately 1–4 m/3½ to 13 ft.

### **Before using for the first time**

**Recharge** flash unit for several hours in order to compensate for the self-discharge during prolonged storage (a characteristic of all accumulators) → Page 19.

### **Couple flash unit to camera**

Unscrew carrying strap or neck strap from camera and secure in bush 17, place contact coupling 18 on contact pin 19 as shown in Fig. G and tighten fixing screw 20.

### **Focus**

to the subject distance in metres or feet, but not over approximately 4 m/13 ft as subjects at any greater distance may not be adequately illuminated.

### **Switch on flash unit**

Push switch **21** past initial resistance fully to the right → Fig. H, red mark **22** indicates "on".

### **Flash ready**

when ready light **23** comes on: with fully charged accumulator after approximately 10 sec.

### **Fire!**

Note camera position → Fig. J: do not mask sensor **24** and reflector **25**. Vertical position (flash unit above camera) is advisable for shadowless flash pictures. The flash is fired by lightly depressing release **16**.

### **Switch off flash unit**

Push switch **21** fully to the left (red mark **22** no longer visible), when no further pictures are immediately intended.

### **Charging flash unit (AC only)**

#### **Check mains voltage**

Only connect charger (type D) when the voltage supply agrees with the voltage stated on the charger plug.

On chargers with voltage selector (between the plug pins): set slot to supply voltage with a coin.

### **Connection for charging**

Push switch **21** to the left in order to switch off charge lock **26**. Plug charger cord into connection **27** → Fig. K, connect charger **28** to mains plug socket. Camera (with or without film cartridge) can remain coupled to flash unit when charging.

### **Charging time**

**After normal discharge:** when the recycling time rises to approximately 30 seconds, recharge as soon as possible for approximately 15 hours to be ready for the next shot. This period may (occasionally!) be exceeded by up to half; frequent overcharging will however damage the accumulator.

**After extreme discharge:** if ready light **23** no longer lights up (for example after forgetting to switch the unit off), recharge immediately for approximately 24 hours.

**After brief period out of use** (up to a few weeks):

before using again charge unit when switched off for approximately 20 minutes. This will reform the flash capacitor and the unit will be fully ready for firing again without loss of accumulator charge.

**After prolonged period out of use:** recharge unit at intervals of a few months in order to compensate for the self-discharge (unavoidable with all accumulators).

### **Practical hints for using the camera**

#### **① The correct film**

for the A 26 is available from your dealer as "126 cartridge film" for 12 or 20 square pictures 28x28 mm. According to application the following are available:

Colour reversal film — gives colour transparencies for projection onto a screen,  
Colour negative film — for coloured prints,

Black and white negative film — for black and white prints.

Ask your Rollei dealer for further details and purchase films as fresh as possible. Branded products of repute guarantee uniform quality standard.

#### **② For carrying the camera**

the following are available: carrying strap and neck strap together with cases for camera or camera with flash unit. After fitting the strap → Page 16 pull the end of the loop out through the hole in the case. When shooting the case is pushed back to expose the camera.

#### **③ Choice of subject**

is of course left to personal preference, but a few rules at the beginning will help avoid mistakes:

brightly illuminated close-up subjects in movement are generally better pictorially than distant small details, a few large colour areas are better than a lot of brightly coloured detail, lively snap shots are more rewarding than monotonous landscapes.

A few more hints: unobserved pictures of children; close-ups of animals in the zoo; sporting events, hiking groups, boat trips, processions, playground scenes, city traffic — these are all "live" pictures.

#### ④ Close-up subjects

at distances between about 2.5 m/8 ft and 1 m/3 1/2 ft require more accurate focusing in order to take advantage of the performance of the lens.

#### ⑤ Green signal

as indication of sufficient subject illumination applies only to the camera when ready for shooting (closed and opened again after the last picture).

#### ⑥ Camera position

in general as shown in Fig. E, but according to requirements other positions are also possible or more practical: for example holding above the head in a crowd or vertically downwards for unobserved snapshots.

#### ⑦ Battery change

Use for example Mallory PX 625 or equivalent batteries of other makes. Undo slotted head screw 29 by turning anti-clockwise with a coin and remove side panel 30 → Fig. L. Rub new battery over with a cloth to remove any oxide film. Push battery (with positive pole against

positive symbol in battery compartment 31) in under spring plate 32 → Fig. M; in doing so only grip by the edge, do not touch back and front. Refit side panel and screw in position.

Battery life 1—2 years, changing once a year is recommended. Closing the camera when not in use saves battery energy as the exposure meter is then switched off.

### Practical hints for using the flash

#### ⑧ Save energy

Switch unit off after use and during prolonged intervals between firing.

#### ⑨ Ready indication

After switching on wait for the ready light 23 to come on, and only then fire the unit. If the ready indicator only comes on after approximately 30 seconds or not at all, the accumulator must be recharged.

#### ⑩ Flashing from the mains

permits in an emergency single (!) flash pictures with severely or fully discharged accumulator. An AC power socket is necessary near the subject:

Connect flash unit (with camera coupled) for charging → Page 19 and wait for ready light to come on. Then pull charger cord out of connection 27 again and switch on flash unit. Take flash picture immediately afterwards as the ready light will extinguish again after a few seconds.

#### **⑪ Flash reflections**

Avoid shooting from positions where the flash will be reflected directly into the camera by reflective objects. Choose position so that frontal reflections (window glass, mirrors or polished surfaces) are eliminated.

#### **⑫ Fill-in flash in daylight**

produces better illumination and more brilliant colours in the picture foreground up to a range of approximately 3 m/10 ft. Operation of the camera with flash unit connected is the same as for normal flash pictures.

#### **⑬ Flashing in public**

It is possible to use flash even when a number of other photographers are taking flash pictures at the same time. The automatic flash control is not affected by the flashes of other photographers (built-in extraneous light trap).

#### **⑭ Charging during travel**

In some cases other voltages and mains plug systems will be found abroad.

As a precaution:

take a suitable charger or adapter to fit the charger plug for use with the plugs in use in the country.

#### **Maintenance and care**

Clean camera according to amount of use at short or long intervals: clean external parts with a soft cloth, glass components with lens cleaning tissue. Unscrew side panel and dust all internal components with a camel hair brush.

Remove battery before long periods out of use → Page 21.

Protect camera and flash unit from sand, water, strong sunlight and vibration; when not in use always close and keep in the case provided.

The International Rollei Service with many authorized and associated photo workshops as well as the Rollei dealers all over the world service Rollei products expertly and will help you with all questions on photography.

## Specification and figures

### A 26

Pocket camera 28 x 28 mm, with automatic programme exposure control for 126 cartridge film.

**Specification:** enclosed compact construction; pull-open outer sleeve providing cover for viewfinder and release, coupled with film advance, shutter cocking, lens lock, exposure measurement and film speed pick-up 18—27 DIN/50—400 ASA; double and blank exposure prevention; indication of film type and exposure number; film advance free-wheel button; special connection with aperture input for C 26 computer electronic flash unit; screw-in bush for carrying or neck strap.

**Automatic exposure control:** exposure meter with CdS photo-conductive cell, measurement based on picture foreground, measuring range 32—8200 cd/m<sup>2</sup>, 39 to 9950 cd/sq. yd., automatic cut-out with camera closed, power supply from Mallory-type cell in internal battery compartment, continuously controlled exposure programme from f/3.5— $\frac{1}{30}$  sec to f/22— $\frac{1}{250}$  sec, green signal for sufficient

subject illumination; servo release with ribbed pressure plate, release travel approx. 0.5 mm.

**Viewfinder system:** direct-vision finder 0,6 x; reflected-image bright-line frame with surrounding area; green signal for sufficient subject illumination, coupled with film speed pick-up.

**Lens:** Carl Zeiss Sonnar 40 mm f/3.5 (made by Rollei) recessed with camera closed and covered by guard plate; 4 elements, 4 components; aperture range f/3.5—f/22; manual focusing on 3 symbols or metre/feet scale from 1 m/3.5 ft.

**Dimensions:** open 112 x 63 x 33 mm, closed 94 x 63 x 33 mm.

**Weight:** 280 g/10 oz.

**Accessories:** carrying strap, neck strap, carrying bag, case for camera with flash unit.

Subject to technical modification without notice.

## Specification and figures

### C 26

Computer electronic flash unit with horizontal format reflector and rechargeable NC accumulator, specially for Rollei A 26; quality guarantee in accordance with DIN 19011.

**Shooting aperture:** automatically set in camera.

**Effective range:** up to approx. 4 m/13 ft.

**Flash duration:**  $t_{0.1}$  approx.  $1/30000 - 1/2500$  sec.

**Recycling time:** approx. 10 sec. with fully charged accumulator.

**Flash capacity:** approx. 40 flashes with fully charged accumulator.

**Reflector:** colour corrected diffusing screen with UV filter.

**Colour temperature:** approx. 5500° K.

**Flash power:** 15 Ws.

**Angle of illumination:** approx. 46° x 60°.

**Acceptance angle of sensor:** approx. 15°.

**NC accumulator:** 2.5 V / 225 mAh, maintenance-free, charging time after normal discharge approximately 15 hours.

**Charger:** Type D, electrically safe by means of disconnecting transformer, protection class II.

**Dimensions:** 75 x 63 x 33 mm /  $2^{31/32}$  x  $2^{1/2}$  x  $1^{5/16}$  in.

**Weight:** 160 g /  $6^{1/4}$  oz.

Subject to technical modification without notice.

## Handling faults and remedies

Symptom	Possible cause	Remedy
Sliding sleeve jammed when closing	Sliding sleeve not previously fully opened	First of all fully open sleeve and then close
Sliding sleeve jammed when opening	Sliding sleeve not previously fully closed	First of all fully close sleeve and then open again



Symptom	Possible cause	Remedy
Shutter does not release	Sliding sleeve not fully open	Fully open sleeve, then close and open again
Film advance jammed before frame -1- appears	Cartridge defect: adhesive strip on film leader too thick	Press release, then advance film as usual to frame -1-
Film advance jammed: sleeve can neither be opened nor closed	Cartridge defect: backing paper end folded over	Do not use force, depress both buttons 7 and 33, then pull down sliding sleeve as usual
Picture underexposed	Green signal not observed	Watch for green signal before each picture (without flash) → Page 17
Next frame number does not appear	Freewheel button 33 inadvertently depressed when opening sleeve	Only hold sleeve by grip → Fig. A
Picture overexposed	Picture taken under extreme bright conditions on high speed film	Use low speed film — e. g. 50 ASA / 18 DIN
Picture sharpness unsatisfactory	Focusing forgotten; particularly noticeable in close-up range 1-2,5 m/3½ to 8 ft	Focus more accurately (particularly in close-up range) → Pages 17 and 21
	With pictures of rapidly moving subjects in dim light	Take these pictures in brighter light; or use faster film
Bright picture areas washed-out and almost colourless, dark picture areas almost black and without discernable detail	Light contrast excessive for colour film: particularly with against-the-light shots, market and street scenes under high sun, beach and mountain scenes at midday	Select different picture area, photograph very bright and very dark subjects separately, change viewpoint or direction; give preference to morning or afternoon sun which is more suitable for photographing
Ready light comes on only after 30 sec. or not at all	Accumulator discharged	Recharge accumulator, see also hint ⑩
Flash picture underexposed	Ready light not waited for	Only fire when ready light 23 comes on → Page 19
Flash picture partially or completely burnt out	Frontal flash reflection	Change viewpoint or direction; particularly in the case of glass windows, polished furniture, tiled walls, etc.